



PHILLIP JEFFRIES LTD. HANGING INSTRUCTIONS

KABUKI JAPANESE SUEDE WALLCOVERING

STOP: DO NOT CUT OR INSTALL UNTIL YOU HAVE READ THESE INSTRUCTIONS!

Thank you for choosing this fine handcrafted wallcovering. For the best results, we believe that a professional wallcovering installer should hang these wallcoverings.

DESCRIPTION:

Luxury for the walls defines the sumptuous **KABUKI JAPANESE SUEDE** collection. The finest quality Japanese suede is meticulously laminated onto a fine paper backing at our factory in Japan. Available in a range of twenty-two colors, from warm classics to bold brights, this collection makes a rich, opulent statement.

PREPARATION:

Before you cut and hang, please be sure you have:

1. The correct wallcovering item and the correct amount of wallcovering to finish the job.
2. Inspect the wallcovering carefully to ensure it is free of defects:
If no defect is evident before installation, the material should be inspected after three (3) strips are installed. If any defect is evident at this time (or at any point in the installation) no additional material should be hung until Phillip Jeffries Ltd. is notified. **NO CLAIMS WILL BE ALLOWED FOR MORE THAN (3) STRIPS ON THE WALL.** All claims must be made within 60 days of the invoice date. No labor claims will be allowed at any time.

**IF YOU HAVE ANY QUESTIONS, PLEASE STOP AND CONTACT
PHILLIP JEFFRIES LTD. BEFORE PROCEEDING**

WALL PREPARATION:

1. The walls to be covered must be properly prepared to insure that the wallcovering will adhere to the wall surface. Even the strongest adhesive can only work when the wall surface is clean and properly prepared.
2. Please be sure to cover old latex paint and new sheetrock or very absorbent walls with a good quality primer that is **SPECIFICALLY MADE FOR WALLCOVERING**. The exact primer must be determined by the installer. However when covering flaky or water based paint, a heavy duty wallcovering primer may provide the best results.
3. Allow the primer to dry thoroughly before hanging.



PHILLIP JEFFRIES LTD.

HANGING INSTRUCTIONS

KABUKI JAPANESE SUEDE WALLCOVERING

STOP: DO NOT CUT OR INSTALL UNTIL YOU HAVE READ THESE INSTRUCTIONS!

INSTALLATION

ADHESIVE

1. We recommend a clear, non-staining, pre-mixed vinyl adhesive.
2. Apply the paste to the back of the paper, which will become flexible and easy to hang. Allow the paste to become tacky prior to hanging (exact time will vary based on temperature, humidity, etc.)
3. Do not add excessive water to the paste as it may cause the backing paper to pull away from the front.

TRIMMING

1. The edges have been pre-trimmed at the factory. However, you may wish to create your own precision trimmed edge by trimming the wallcovering on your work table.
2. Trim edges with a VERY sharp razor blade. Change your blades often.

TIPS

1. Use a soft brush or cloth when hanging, as to not damage the face of the wallcovering.
2. Consider using a light painters tape to cover the edges of previously installed strips, so that the paste coming out from the seams will not settle on the installed strips.
3. DO NOT allow paste or excessive water to stain the front of the wallcovering. Both paste and excessive water will change the color on the face of the paper.
4. Paste, trim and hang one strip at a time.
5. Over the years, we have found that hanging the Japanese suede wallcoverings in the same direction, without reversing the strips, has produced the most even shading. However, we leave it up to each installer on the job to make the final decision.
6. Gently smooth the wallcovering using a plastic smoother. Do not use a seam roller.
7. The Kabuki Japanese Suede wallcoverings are wipeable with a damp cloth or can be vacuumed with a small brush attachment.