



PHILLIP JEFFRIES LTD. HANGING INSTRUCTIONS

ROCK STAR - SOLID WALLCOVERING

STOP: DO NOT CUT OR INSTALL UNTIL YOU HAVE READ THESE INSTRUCTIONS!

Thank you for choosing this fine handcrafted wallcovering. For the best results, we believe that a professional wallcovering installer should hang these wallcoverings.

DESCRIPTION:

Clear crystals blanket the ground of seven beautifully colored papers in the shimmering **ROCK STAR - Solid**. This pattern is one of three delicious wallcoverings that embody the dramatic *Rock Star* collection. Items 4501-4507 are named **Rock Candy / Rock Star**.

PREPARATION:

Before you cut and hang, please be sure you have:

1. The correct wallcovering and the correct amount of wallcovering to finish the job.
2. Inspect the wallcovering carefully to ensure it is free of defects:

If no defect is evident before installation, the material should be inspected after three (3) strips are installed. If any defect is evident at this time (or at any point in the installation) no additional material should be hung until Phillip Jeffries Ltd. is notified. **NO CLAIMS WILL BE ALLOWED FOR MORE THAN (3) STRIPS ON THE WALL.** All claims must be made within 60 days of the invoice date. No labor claims will be allowed at any time.

BUILDING & MATERIAL CONDITIONS: The building must be weather-tight with HVAC settings (including pressure, temperature and relative humidity) the same as those of an occupied building for three days prior to, throughout installation and three days after installation. The walls must be structurally sound including elimination of sources of moisture accumulation into the wall or wall cavity. The wallcovering must be in a clean and dry condition and must be stored at normal occupied building temperature and humidity for at least three days prior to installation. All adhesives and primers must be new, good quality, commercial grade materials, which have not been contaminated.

IF YOU HAVE ANY QUESTIONS, PLEASE STOP AND CONTACT
PHILLIP JEFFRIES LTD. BEFORE PROCEEDING.

WALL PREPARATION:

1. The walls to be covered must be properly prepared to insure that the wallpaper will adhere to the wall surface. Even the strongest adhesive can only work when the wall surface is clean and properly prepared.
2. Phillip Jeffries recommends that installers use a hard, acrylic, pigmented, wall-protecting primer that is **SPECIFICALLY** made for WALLCOVERING INSTALLATION and WALL PROTECTION.

DO NOT utilize R-35 on its own as a primer as R-35 is a light-duty adhesion promoting sizer, not a wall-protecting, wallcovering primer.

3. Allow the primer to dry thoroughly before hanging.



PHILLIP JEFFRIES LTD.

HANGING INSTRUCTIONS

ROCK CANDY WALLCOVERING

STOP: DO NOT CUT OR INSTALL UNTIL YOU HAVE READ THESE INSTRUCTIONS!

INSTALLATION

ADHESIVE

1. We recommend a heavy duty clear, pre-mixed vinyl adhesive with a low water content.
2. Apply the paste to the back of the paper, which will become flexible and easy to hang. Allow wallcovering to relax prior to hanging. Usual relaxing time is 5-15 minutes; DO NOT relax wallcovering longer.
3. Do not use too much adhesive to avoid seam tearing stains on wallcovering.
4. Do not add excessive water to the paste as it may cause the backing paper to pull away from the front.
5. DO NOT get paste on the face of wallcovering. If paste does accidentally get on the face of the wallcovering, blot off excess paste immediately with a soft damp cloth soaked with a mild detergent. Do not scrub and rub.

TRIMMING

1. The edges have been pre-trimmed at the factory. However you may wish to create your own precision trimmed edge by trimming the wallcovering on your work table.
2. To trim this wallcovering, place your strip face down onto the work table. Use your straight edge to create a template. Use a new blade and cut a straight edge by cutting through the backside of the paper.
3. Trim edges with a VERY sharp razor blade. Change your blades often.
4. This wallcovering CANNOT be double cut on the wall.

TIPS

1. Use a soft brush or cloth when hanging, so that you do not damage the face of the wallcovering. Smooth until all air bubbles are removed.
2. DO NOT crease the wallcovering.
3. Remove any loose glass beads that might be stuck to the back side of wallcovering to ensure a smooth installation.
4. Paste, trim and hang one strip at a time.
5. DO NOT reverse hang the strips.
6. Consider using a light painters tape to cover the edges of previously installed strips, so that the paste coming out from the seams will not settle on the installed strips.
7. Gently smooth the wallcovering using a plastic smoother. Do not use a seam roller.