



PHILLIP JEFFRIES LTD. HANGING INSTRUCTIONS

SUGAR CANE WALLCOVERING

STOP: DO NOT CUT OR INSTALL UNTIL YOU HAVE READ THESE INSTRUCTIONS!

Thank you for choosing this fine handcrafted wallcovering. For the best results, we believe that a professional wallcovering installer should hang these wallcoverings.

DESCRIPTION:

Luminous stripes effortlessly intertwine in pattern **SUGAR CANE** to create a 3-dimensional, vertical texture in six colors. This pattern is one of two delicious wallcoverings that embody the dramatic *Wall Candy* collection.

PREPARATION:

Before you cut and hang, please be sure you have:

1. The correct wallcovering and the correct amount of wallcovering to finish the job.
2. Inspect the wallcovering carefully to ensure it is free of defects:
If no defect is evident before installation, the material should be inspected after three (3) strips are installed. If any defect is evident at this time (or at any point in the installation) no additional material should be hung until Phillip Jeffries Ltd. is notified. **NO CLAIMS WILL BE ALLOWED FOR MORE THAN (3) STRIPS ON THE WALL.** All claims must be made within 60 days of the invoice date. No labor claims will be allowed at any time.

**IF YOU HAVE ANY QUESTIONS, PLEASE STOP AND CONTACT
PHILLIP JEFFRIES LTD. BEFORE PROCEEDING**

WALL PREPARATION:

1. The walls to be covered must be properly prepared to insure that the wallcovering will adhere to the wall surface. Even the strongest adhesive can only work when the wall surface is clean and properly prepared.
2. Please be sure to cover old latex paint and new sheetrock or very absorbent walls with a good quality primer that is **SPECIFICALLY MADE FOR WALLCOVERING**. The exact primer must be determined by the installer. However when covering flaky or water based paint, a heavy duty wallcovering primer may provide the best results.
3. Allow the primer to dry thoroughly before hanging.



PHILLIP JEFFRIES LTD.

HANGING INSTRUCTIONS

SUGAR CANE WALLCOVERING

STOP: DO NOT CUT OR INSTALL UNTIL YOU HAVE READ THESE INSTRUCTIONS!

INSTALLATION

ADHESIVE

1. We recommend a heavy duty clear, pre-mixed vinyl adhesive with a low water content.
2. Apply the paste to the back of the paper, which will become flexible and easy to hang. Allow wallcovering to relax prior to hanging. Usual relaxing time is 5-15 minutes; DO NOT relax wallcovering longer.
3. Do not use too much adhesive to avoid seam tearing or stains on wallcovering.
4. Do not add excessive water to the paste as it may cause the backing paper to pull away from the front.
5. DO NOT get paste on the face or edges of the wallcovering. If paste does accidentally get on the face of the wallcovering, blot off excess paste immediately with a soft damp cloth soaked with very mild detergent. Do not scrub and rub.

TRIMMING

1. The edges have been pre-trimmed at the factory. However you may wish to create your own precision trimmed edge by trimming the wallcovering on your work table.
2. Trim edges with a VERY sharp razor blade. Change your blades often.
3. This wallcovering can also be double cut on the wall.

TIPS

1. Remove any loose glass beads that might be stuck to the back side of wallcovering to ensure a smooth installation.
2. DO NOT crease the wallcovering
3. Use a soft brush or cloth when hanging, so that you do not damage the face of the wallcovering. Smooth until all air bubbles are removed.
4. Paste, trim and hang one strip at a time.
5. DO NOT reverse hang the strips.
6. Consider using a light painters tape to cover the edges of previously installed strips, so that the paste coming out from the seams will not settle on the installed strips.
7. Gently smooth the wallcovering using a plastic smoother. Do not use a seam roller.