



PHILLIP JEFFRIES LTD.

HANGING INSTRUCTIONS

JACKSON SQUARE WALLCOVERING

STOP: DO NOT CUT OR INSTALL UNTIL YOU HAVE READ THESE INSTRUCTIONS!

Thank you for choosing this fine handcrafted wallcovering. For the best results, we believe that a professional wallcovering installer should hang these wallcoverings.

DESCRIPTION:

The handcrafted, authentic wood wallcovering **JACKSON SQUARE** is a unique mosaic pattern of 5.9" wood squares. Made from Paulownia wood known in Japan as the "good luck" princess tree, the wood is first hand cut into thin veneer sheets. Additional strips are then scattered atop the veneer's surface for a completely random design and applied with a wash of metallic color. Hand cut into the squares, the material is laminated onto a recycled paper backing and then applied with an aqueous resin finish for protection and ease of maintenance.

PREPARATION:

Before you cut and hang, please be sure you have:

1. The correct wallcovering and the correct amount of wallcovering to finish the job.
2. Inspect the wallcovering carefully to ensure it is free of defects:

If no defect is evident before installation, the material should be inspected after three (3) strips are installed. If any defect is evident at this time (or at any point in the installation) no additional material should be hung until Phillip Jeffries Ltd. is notified. **NO CLAIMS WILL BE ALLOWED FOR MORE THAN (3) STRIPS ON THE WALL.** All claims must be made within 60 days of the invoice date. No labor claims will be allowed at any time.

BUILDING & MATERIAL CONDITIONS: The building must be weather-tight with HVAC settings (including pressure, temperature and relative humidity) the same as those of an occupied building for three days prior to, throughout installation and three days after installation. The walls must be structurally sound including elimination of sources of moisture accumulation into the wall or wall cavity. The wallcovering must be in a clean and dry condition and must be stored at normal occupied building temperature and humidity for at least three days prior to installation. All adhesives and primers must be new, good quality, commercial grade materials, which have not been contaminated.

IF YOU HAVE ANY QUESTIONS, PLEASE STOP AND CONTACT
PHILLIP JEFFRIES LTD. BEFORE PROCEEDING.

WALL PREPARATION:

1. The walls to be covered must be properly prepared to insure that the wallpaper will adhere to the wall surface. Even the strongest adhesive can only work when the wall surface is clean and properly prepared.
2. Phillip Jeffries recommends that installers use a hard, acrylic, pigmented, wall-protecting primer that is **SPECIFICALLY** made for WALLCOVERING INSTALLATION and WALL PROTECTION.

DO NOT utilize R-35 on its own as a primer as R-35 is a light-duty adhesion promoting sizer, not a wall-protecting, wallcovering primer.

3. Allow the primer to dry thoroughly before hanging.



PHILLIP JEFFRIES LTD.

HANGING INSTRUCTIONS

JACKSON SQUARE WALLCOVERING

STOP: DO NOT CUT OR INSTALL UNTIL YOU HAVE READ THESE INSTRUCTIONS!

INSTALLATION

ADHESIVE

1. We recommend a heavy duty clay based paste without too much moisture. If there is too much moisture in the paste it will cause the material to bubble.
2. Size walls with the same paste you use to install. Size 100% of surface and let it dry completely before installing one strip. This will give you good tack for installation.
3. Use strips in the exact order as they are cut from roll.
4. Paste one piece at a time, soak 5 minutes then proceed with installation.
5. **DO NOT** get paste on the face of the wallcovering. If paste does accidentally get on the face of the wallcovering, blot off excess paste immediately with a soft, moist rag and dry moisture with a dry towel. Do not scrub or rub. When wiping this material, there will be a slight residue of the finish that will come off. Therefore, minimal wiping is suggested so not to alter the finish of the wallcovering.
6. Use a soft brush or smoothing blade of flexible plastic designed for fabrics when hanging for smoothing and removing air pockets.

TRIMMING

1. The edges have been pre-trimmed at the factory. However, you may wish to create your own precision trimmed edge by trimming the wallcovering on your work table.
2. Trim the edges while paper is dry.
3. Trim edges with a **VERY** sharp razor blade. Change your blades often.

MATCHING

1. Squares are 5.9" x 5.9" inches (15 CM. x 15CM) and are a straight match.
2. The design of the wood strips scattered atop each the 5.9" squares is a random pattern that is hand applied.
3. Cut and apply strips as they come from the roll.

TIPS

1. In some instances, you may notice a bubbling effect where too much moisture is in the paste. If you notice the wallcovering bubbling after the 1st 3 strips, let it dry overnight before proceeding. If the bubbles **DO NOT** disappear the following morning, call Phillip Jeffries for additional instructions before proceeding.
2. This is a special natural wood product and special care should be taken when installing. **DO NOT** allow paste or excessive water to stain the front of the wallcovering. Both paste and excessive water will change the color of the wood veneer on the face of the paper.
3. Inspect installation after applying no more than three (3) strips. If any defect is evident at this time, no additional material should be hung until Phillip Jeffries Ltd. is notified.
4. Subtle shading differences between strips tend to soften over time as the wallcovering begins to oxidize.