



# PHILLIP JEFFRIES LTD. HANGING INSTRUCTIONS

## BAROQUE EMBROIDERY- COMPANION MOIRÉ

**STOP: DO NOT CUT OR INSTALL UNTIL YOU HAVE READ THESE INSTRUCTIONS!**

Thank you for choosing this fine handcrafted wallcovering. For the best results, we believe that a professional wallcovering installer should hang these wallcoverings.

### **DESCRIPTION:**

The solid **COMPANION MOIRÉ** to the **BAROQUE EMBROIDERY** collection of wallcoverings. Available in four shimmering colorways, the solid moiré is a beautiful companion to the opulent collection.

### **PREPARATION:**

Before you cut and hang, please be sure you have:

1. The correct wallcovering and the correct amount of wallcovering to finish the job.
2. Inspect the wallcovering carefully to ensure it is free of defects:  
If no defect is evident before installation, the material should be inspected after three (3) strips are installed. If any defect is evident at this time (or at any point in the installation) no additional material should be hung until Phillip Jeffries Ltd. is notified. **NO CLAIMS WILL BE ALLOWED FOR MORE THAN (3) STRIPS ON THE WALL.** All claims must be made within 60 days of the invoice date. No labor claims will be allowed at any time.

**IF YOU HAVE ANY QUESTIONS, PLEASE STOP AND CONTACT  
PHILLIP JEFFRIES LTD. BEFORE PROCEEDING**

### **WALL PREPARATION:**

1. The walls to be covered must be properly prepared to insure that the wallpaper will adhere to the wall surface. Even the strongest adhesive can only work when the wall surface is clean and properly prepared.
2. Please be sure to cover old latex paint and new sheetrock or very absorbent walls with a good quality primer that is **SPECIFICALLY MADE FOR WALLCOVERING**. The exact primer must be determined by the installer. However when covering flaky or water based paint, a heavy duty wallcovering primer may provide the best results.
3. Allow the primer to dry thoroughly before hanging.



# PHILLIP JEFFRIES LTD.

## HANGING INSTRUCTIONS

### BAROQUE EMBROIDERY- COMPANION MOIRÉ

**STOP: DO NOT CUT OR INSTALL UNTIL YOU HAVE READ THESE INSTRUCTIONS!**

#### INSTALLATION

##### ADHESIVE

1. We recommend a clear, non-staining, pre-mixed vinyl adhesive.
2. Apply the paste to the back of the paper, which will become flexible and easy to hang. Allow the paste to become tacky prior to hanging (exact time will vary based on temperature, humidity, etc.)
3. Do not add excessive water to the paste as it may cause the backing paper to pull away from the front.

##### TRIMMING

1. The edges have been pre-trimmed at the factory. However, you may wish to create your own precision trimmed edge by trimming the wallcovering on your work table.
2. Trim edges with a VERY sharp razor blade. Change your blades often.

##### ABOUT MOIRÉ

1. Over the years, we have found that hanging the moiré wallcoverings in the same direction, without reversing the strips, has produced the most even shading. However, we leave it up to each installer on the job to make the final decision.
2. Please take a few minutes to lie out the strips to create the most consistent shading before hanging.
3. The natural finish may show some shade variations from strip to strip. This is most likely to be noticed soon after installation is completed. However, within a fairly short period of time of being exposed to air the Wallcovering will start to oxidize and any uneven shading will become less noticeable.

##### TIPS

1. Use a soft brush or cloth when hanging, so that you do not damage the face of the wallcovering.
2. DO NOT allow paste or excessive water to stain the front of the wallcovering. Both paste and excessive water will change the color of the face of the wallcovering.
3. Paste, trim and hang one strip at a time.
4. Consider using a light painters tape to cover the edges of previously installed strips, so that the paste coming out from the seams will not settle on the installed strips.
5. Gently smooth the wallcovering using a plastic smoother. Do not use a seam roller.
6. This wallcovering has been treated with a stain repellent finish to allow the washing of stains. Treat stains as soon as possible with clean water, using a soft cloth. Try to use a lifting action, avoid hard rubbing of spots to prevent discoloration. Take special care in cleaning dark colors to avoid leaving "light marks" on the wallcovering.