



# PHILLIP JEFFRIES LTD. HANGING INSTRUCTIONS

## LACQUERED STRIÉ WALLCOVERING

**STOP: DO NOT CUT OR INSTALL UNTIL YOU HAVE READ THESE INSTRUCTIONS!**

Thank you for choosing this high quality vinyl wallcovering. For the best results, we believe that a professional wallcovering installer should hang these wallcoverings.

### DESCRIPTION:

Imagine your walls dripping with high gloss lacquer with a vertical texture! Our 54" Type II vinyl LACQUERED STRIÉ is embossed with a vertical strié pattern that is virtually seamless. Too luxurious not to fall in love with, the LACQUERED STRIÉ is conveniently matched with coordinating solids.

### PREPARATION:

Before you cut and hang, please be sure you have:

1. The correct wallcovering and the correct amount of wallcovering to finish the job.
2. Inspect the wallcovering carefully to ensure it is free of defects:

If no defect is evident before installation, the material should be inspected after three (3) strips are installed. If any defect is evident at this time (or at any point in the installation) no additional material should be hung until Phillip Jeffries Ltd. is notified. **NO CLAIMS WILL BE ALLOWED FOR MORE THAN (3) STRIPS ON THE WALL.** All claims must be made within 30 days of the invoice date. No labor claims will be allowed at any time.

**BUILDING & MATERIAL CONDITIONS:** The building must be weather-tight with HVAC settings (including pressure, temperature and relative humidity) the same as those of an occupied building for three days prior to, throughout installation and three days after installation. The walls must be structurally sound including elimination of sources of moisture accumulation into the wall or wall cavity. The wallcovering must be in a clean and dry condition and must be stored at normal occupied building temperature and humidity for at least three days prior to installation. All adhesives and primers must be new, good quality, commercial grade materials, which have not been contaminated.

IF YOU HAVE ANY QUESTIONS, PLEASE STOP AND CONTACT  
**PHILLIP JEFFRIES LTD. BEFORE PROCEEDING.**

### WALL PREPARATION:

1. The walls to be covered must be properly prepared to insure that the wallpaper will adhere to the wall surface. Even the strongest adhesive can only work when the wall surface is clean and properly prepared.
2. Phillip Jeffries recommends that installers use a hard, acrylic, pigmented, wall-protecting primer that is SPECIFICALLY made for WALLCOVERING INSTALLATION and WALL PROTECTION.

*DO NOT utilize R-35 on its own as a primer as R-35 is a light-duty adhesion promoting sizer, not a wall-protecting, wallcovering primer.*

3. Allow the primer to dry thoroughly before hanging.



# PHILLIP JEFFRIES LTD.

## HANGING INSTRUCTIONS

# LACQUERED STRIÉ WALLCOVERING

**STOP: DO NOT CUT OR INSTALL UNTIL YOU HAVE READ THESE INSTRUCTIONS!**

## INSTALLATION

### ADHESIVE

1. We recommend a clay based adhesive. During our tests, installer successfully used undiluted Roman's Clay 732 and in a second test, Gibson Homans Shur-Stick 111 Clay.
2. Whip clay with paste beater and use full strength. If paste container has already been opened, make sure that no dried flakes fall in. Due to its extreme high sheen, Lacquered Strié will show any paste lumps or clots upon drying. Apply paste at full strength with short nap roller or pasting machine. We recommend a hard plastic smoother be used for wall application.
3. Tip: Wrap your plastic smoother edge in a soft clean cloth to prevent micro-scratching in high sheen lacquered type wallcoverings.

### PROTECTIVE LAYER

1. Each bolt of the COLORED Lacquered Strie (NOT METALLIC) has a PROTECTIVE CLEAR SHEET on surface of wallcovering that SHOULD BE REMOVED BEFORE goods are cut and installed. NO CLEAR SHEET is present on METALLIC COLORS.

### TRIMMING

1. We strongly recommend creating a precision trimmed edge by MAKING A DOUBLE CUT ON THE WALL to create as fine a seam as possible.
2. Trim edges with a VERY sharp razor blade. Change your blades often.

### MATCHING

1. Lacquered Strié creates the effect of a random pattern of vertical lines and therefore is a random match.

### TIPS

1. All strips should be hung in sequence, as they come off the roll.
2. Remove protective clear sheet off of the wallcovering surface prior to being cut and installed.
3. Install each sheet on the wall using a short bristle brush or flexible broadknife, wrapping the front edge of tool with a clean cloth to avoid surface scratches or marks.
4. If you experience difficulty with edges curling up, we suggest using a heat gun or hair dryer at low setting to coax edges to lie flat.
5. Apply material above doors and windows as it comes off the roll, DO NOT SKIP.
6. Remove excess adhesive and dirt from wallcovering surface and seams immediately, using a clean sponge or damp cloth frequently rinsed in clean, warm water.
7. All vinyl wallcoverings should be washed regularly to prevent dirt and grime from accumulating. Depending on traffic (light, medium, heavy), vinyl should be washed two or three times a year. Ordinary dirt can be removed with mild soap and warm water. Dry wallcovering with a soft, lint-free cloth or towel. For more difficult stains that are only surface deep, the use of a stronger detergent is recommended. WE RECOMMEND ALL CLEANERS BE TESTED IN AN INCONSPICUOUS AREA TO INSURE COMPATIBILITY WITH THE WALLCOVERING.