



PHILLIP JEFFRIES LTD. HANGING INSTRUCTIONS

TAILORED LINENS WALLCOVERING

STOP: DO NOT CUT OR INSTALL UNTIL YOU HAVE READ THESE INSTRUCTIONS!

Thank you for choosing this fine handcrafted wallcovering. For the best results, we believe that a professional wallcovering installer should hang these wallcoverings.

DESCRIPTION:

Inspired by the tailored look of men's suiting, **TAILORED LINENS** is reminiscent of what all wallcovering should be: classic, functional and always in style. Our latest collection of fabric for the walls, **TAILORED LINENS** subtle horizontal weave and soft luster create a sophisticated polish with a hint of texture. Woven of fine rayon yarns and laminated to a paper backing, the collection is available in range of ten chic suiting inspired neutrals – from deep charcoal to classic camel.

PREPARATION:

Before you cut and hang, please be sure you have:

1. The correct wallcovering and the correct amount of wallcovering to finish the job.
2. Inspect the wallcovering carefully to ensure it is free of defects:

If no defect is evident before installation, the material should be inspected after three (3) strips are installed. If any defect is evident at this time (or at any point in the installation) no additional material should be hung until Phillip Jeffries Ltd. is notified. **NO CLAIMS WILL BE ALLOWED FOR MORE THAN (3) STRIPS ON THE WALL.** All claims must be made within 60 days of the invoice date. No labor claims will be allowed at any time.

BUILDING & MATERIAL CONDITIONS: The building must be weather-tight with HVAC settings (including pressure, temperature and relative humidity) the same as those of an occupied building for three days prior to, throughout installation and three days after installation. The walls must be structurally sound including elimination of sources of moisture accumulation into the wall or wall cavity. The wallcovering must be in a clean and dry condition and must be stored at normal occupied building temperature and humidity for at least three days prior to installation. All adhesives and primers must be new, good quality, commercial grade materials, which have not been contaminated.

IF YOU HAVE ANY QUESTIONS, PLEASE STOP AND CONTACT
PHILLIP JEFFRIES LTD. BEFORE PROCEEDING.

WALL PREPARATION:

1. The walls to be covered must be properly prepared to ensure that the wallpaper will adhere to the wall surface. Even the strongest adhesive can only work when the wall surface is clean and properly prepared.
2. Please be sure to cover old latex paint and new sheetrock or very absorbent walls with a good quality primer that is **SPECIFICALLY MADE FOR WALLCOVERING**. The exact primer must be determined by the installer. However when covering flaky or water based paint, a heavy duty wallcovering primer may provide the best results. If unsure, perform a paint adhesion test.
3. Allow the primer to dry thoroughly before hanging.



PHILLIP JEFFRIES LTD.

HANGING INSTRUCTIONS

TAILORED LINENS WALLCOVERING

STOP: DO NOT CUT OR INSTALL UNTIL YOU HAVE READ THESE INSTRUCTIONS!

INSTALLATION

ADHESIVE

1. We recommend a premium clear, full strength, pre-mixed vinyl adhesive.
2. Apply the paste to the back of the paper, which will become flexible and easy to hang. Allow the paste to become tacky prior to hanging (exact time will vary based on temperature, humidity, etc.) In our testing, material was booked, rolled up like "cigars" and allowed to stand for 10 minutes. However, final booking decisions are up to the installer.
3. Do not add excessive water to the paste as it may cause the backing paper to pull away from the front.
4. It is important to keep the face of the wallcovering free of adhesive & water to avoid staining or dull spots.

TRIMMING

1. The edges have been pre-trimmed at the factory. However, we recommend creating a precision cut on the table or double cutting on the wall to create as fine a seam as possible.
2. Trim edges with a VERY sharp razor blade to avoid dragging the fibers. Change your blades often.

TIPS

1. Use a soft brush or cloth when hanging, so that you do not damage the face of the wallcovering.
2. DO NOT allow paste or water to stain the front of the wallcovering. Both paste and excessive water will create dull spots and/ or change the color of the face of the paper.
3. We have found that hanging the **Tailored Linens** wallcovering in the same direction, without reversing the strips, has produced the most even shading. However, we leave it up to each installer on the job to make the final decision.
4. Paste, trim and hang one strip at a time.
5. Consider using a light painters tape to cover the edges of previously installed strips, so that the paste coming out from the seams will not settle on the installed strips.
6. To avoid the possibility of seam separation, perform a paint adhesion test before hanging. If there is poor paint adhesion, consider using a blank stock lining paper on the wall before **Tailored Linens** is applied, to avoid shrinkage.
7. Gently smooth the wallcovering using a plastic smoother. Do not use a seam roller.
8. Wallcovering may be cleaned using a soft brush attachment of a vacuum cleaner.